


#187 Lap Type Square Stair Nosing

Manufacturer

Flexco Corporation
1401 East 6th Street
Tuscumbia, AL USA 35674
Phone (800) 633-3151
Fax (800) 346-9075
Email: info@flexcofloors.com,
solutions@rhctechincal.com
Internet: www.flexcofloors.com

Product Description

Co-Extruded Thermoplastic formulation designed to provide excellent resistance to scuffing and gouging while meeting ADA recommendations for transitioning different flooring surfaces



Attach
color submittal sample
here

Technical Data

ASTM E84 - Surface Burning: **Class A**
ASTM E648 (NFPA 253) - Critical Radiant Flux: **Class I,**
> .045 W/cm2
ASTM E662 (NFPA 258) - Smoke Density: **Passes,**
<450
Acclimation Time: **48 Hours**
Storage & Acclimation Temperature: **65 ° - 85 ° F**

Adhesives*

Excelsior EN-610, Adhesive should be used on all stair nosings. Flexco does not recommend the use of "stair tread" installation tape or pressure sensitive adhesive as adequate adhesives for the installation of any Flexco Vinyl Flooring Accessories, especially stair nosings.

Installation*

Vinyl Accessories are designed for interior use only with temperatures maintained from 65°F (19°C) and 85°F (30° C). The flooring installer must inspect all material for manufacturing imperfections and irregularities prior to installation. Before installing, confirm accessory placement and the placement of adjoining material per design specifications.

Maintenance*

Wipe the Vinyl Flooring Accessories with a mild solution of Neutral pH cleaner such as Excelsior NC-900 or equivalent. Do not use detergents, abrasive cleaners or "mop and shine" products as they will dull the look of the flooring.

Technical Document Support

Additional product resources and technical documents are available online at: www.flexcofloors.com
For additional technical support, send an e-mail to: solutions@rhctechincal.com

Warranty

FLEXCO Provides a 1 year Limited Warranty on all Vinyl Accessories. For additional information, see associated Warranty documents.

**For complete adhesive, installation & maintenance instructions, visit www.flexcofloors.com*