

Health Design Wall Base Maintenance

- Some disinfectants, cleaning agents, floor maintenance products and pesticides may stain or damage the surface of the Health Design Wall Base
- Clean the Health Design Wall Base with a soft cloth dampened with a neutral pH cleaner and warm water solution
- Rinse sparingly with water
- If applying finish to flooring, take necessary precautions to keep finish from the Health Design Wall Base
- If applying finish to the Health Design Wall Base, test inconspicuous area first for compatibility

COMPANY INFORMATION

Flexco Corporation
1401 East 6th Street
Tuscumbia, AL, USA 35674
Phone: (800) 633-3151

Email: info@flexcofloors.com, technical@flexcofloors.com

Internet: www.flexcofloors.com

